

USER MANUAL

BUMP CAP MODEL: Neriox Air, 533532, 7 cm
Neriox Sport Air, 533533, 3 cm

Please read carefully

WARNING! THIS IS NOT AN INDUSTRIAL SAFETY HELMET

This bump cap does not provide protection against the effects of falling or thrown objects, or moving suspended load. It should not be used instead of an industrial safety helmet as specified in EN397.

It is designed for your personal safety. It doesn't provide unlimited head protection.

Bump caps should not be adapted for the purpose of fitting attachments in any way not recommended by the bump cap manufacturer.

This bump cap is made to absorb the energy of a blow by partial destruction or damage to the shell and the harness, if fitted, and even though such damage may not be readily apparent, any bump cap subjected to severe impact should be replaced.

Never modify this device other than those recommended by the manufacturer.

Never use the cap if it is cracked or cut. Do not use any dissolver, paint or glue on the caps.

Adjustment:

For adequate protection this bump cap must fit or be adjusted to the size of the user's head.

Use the Velcro to make the cap size perfectly fit to your own head.

Cleaning and disinfection:

To disinfect and clean your bump cap, use warm soapy water and dry it with a soft cloth.

Do not apply paint, solvent, adhesives or self-adhesive labels, except in accordance with instructions from the bump cap manufacturer.

Storage and Transportation:

Store the cap clean and dry in normal room temperature.

Transportation in original box recommended.

Do not carry loose with items such as tools or other sharp metal objects.

Don't store the bump cap on rear window shelf of your car.

Accessories and appropriate spare parts:

The bump cap Maverick series doesn't permit to fix any accessories and any spare parts are available for this product.

The attention of users is also drawn to the danger of modifying or removing any of original component parts of the bump cap, other than recommended by the bump cap manufacturer.

Maintenance and expiration date:

Every cap which was exposed to any hazards should be replaced, also when there is no damage obviously. Before each use the cap should be inspected for cracks, cuts or other damages. Any cap involved in an accident should be replaced for safety reason.

The inner shell expiration date is 4 years after production, the inner shell cannot be repaired and if damaged you need to buy the new one from the most nearby dealer.

Tests of absorption, penetration, dimensional are performed in a testing laboratory to fulfill the requirements of the EN 812:2012 European standard.

Explanation of the marking on the product (Shell):



Manufacture address: Brüttsch/Rüegger Tools Ltd., Heinrich Stutz-Strasse 20, 8902 Urdorf, Switzerland

Optional requirement :-20° C (this means on very low temperature the helmet also can pass the shock absorbing test and resistance to penetration test)



Those protectors fulfill with the requirements of the PPE European regulation EU 2016/425

Notified body:

ALIENOR CERTIFICATION (#2754)
21 Rue Albert Einstein, ZA du Sanital,
86100 CHATELLERAULT - FRANCE

Conform to EN 812:2012

The user information is delivered with each bump cap in commercially packaging. The and EU declaration of conformity is on the website www.neriox.tools under the item number.

www.neriox.tools

MANUFACTURER:

Brüttsch/Rüegger Tools Ltd.
Heinrich Stutz-Strasse 20
8902 Urdorf, Switzerland

Tel: +41 44 736 63 63

Fax: +41 44 736 64 49